




Ref. 7067217
7067218
7067219

- NOTICE DE MONTAGE / ASSEMBLY



Bulb not included
ampoule non incluse





FR – Consignes de sécurité

Veuillez lire attentivement cette notice et la conserver pour une utilisation ultérieure. La sécurité de ce luminaire est garantie sous réserve du respect des instructions indiquées ci-joint. Le fabricant décline toute responsabilité en cas de dommages dus à un défaut de montage ou d'utilisation.

L'alimentation électrique doit être coupée avant de procéder au montage, à l'entretien, au changement de l'ampoule ou au nettoyage. Vérifiez si les spécificités électriques de ce luminaire sont compatibles avec votre installation. Ce luminaire est exclusivement destiné à une utilisation en intérieur, hors pièces humides. Veillez à ne pas endommager les câbles lors du montage. Si le câble extérieur souple ou le cordon de ce luminaire est endommagé, il doit être exclusivement remplacé par le fabricant, son service de maintenance ou toute personne de qualification équivalente, cela afin d'éviter tout risque. Attendre le refroidissement complet de la lampe avant le changement de l'ampoule. Ne jamais dépasser la puissance maximale de l'ampoule indiquée sur l'étiquette.

EN – Safety instructions

Please read this instruction manual carefully and keep it for further reference. This light is guaranteed to be safe provided that the instructions below are followed. The manufacture shall not be liable for any damage from incorrect assembly or use. Power must be disconnected before assembly, maintenance, changing the bulb or cleaning. Check that the electrical specifications of this light are compatible with your installation. This light is designed solely for indoor use, except damp rooms. Care should be taken not to damage the cables during assembly. If the flexible external cable or the cord of this light are damaged, they must be replaced by the manufacturer, the manufacturer's maintenance service or by equivalent qualified person, to avoid any risk. Wait until the lamp has become completely cool before changing the bulb. Do not exceed the maximum wattage for the light bulb as shown on the label.



FR /

Usage intérieur uniquement



Ce symbole, apposé sur le produit ou son emballage, indique que ce produit ne doit pas être jeté avec les ordures ménagères. Il doit être déposé dans un point de collecte adapté au recyclage des équipements électriques et électroniques. En vous assurant que ce produit est éliminé correctement, vous contribuez à prévenir les conséquences potentiellement néfastes pour l'environnement et la santé humaine. Le recyclage des matériaux contribue à préserver les ressources naturelles.



EN/

Indoor use only



This symbol on the product or on its literature and packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring that this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health, which could be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local government office, your household waste disposal service or the shop where you purchased the product.



Données Techniques :

Modèle / Model : 7067217, 7067218, 7067219

Description : Lampe de table / Table lamp

Tension Secteur / Main Voltage : 220-240V, 50/60 Hz

Ampoule / Bulb : E14 / Max. 25W



Importé par / Imported by : SAS Lebrun 62510 Arques France

Fabriqué en Chine / Made in China

Lebrun.fr/consommateurs